

INSTRUCTIONS FOR USE OF COLORED GELCOAT

1. Clean cracks that are to be filled by use of knife or similar instrument.
2. Mix small amount of gelcoat with CAB-O-SEL, if repairs are to be made on vertical surface. Add and mix Cab-O-Sel until desired consistency is reached. Mix very thoroughly.
3. Add hardner (MEK) six (6) drops to one ounce of Gelcoat. (Should start to set up in about one-half ($\frac{1}{2}$) hour at 75°.)
4. Allow to stand several hours or over night and sand smooth with #400 wet sandpaper.
5. After smooth, apply a coat of paste wax to make it shine.

1-3-66
DEV:ns
9-20-68