

INSTRUCTIONS FOR USE OF AIRSTREAM SEPTIC TANK

1964 Models

Our septic tank is really a holding tank which with a little conservation of water will allow use of the toilet away from sewer facilities for several days.

Its operation is quite simple:

When the use of the tank is anticipated, the gate valve on the back of the tank located in the rear bumper compartment should be pushed closed.

When emptying the tank, attach sewer hose to sewage outlet with outlet end of hose in sewer fitting and lying in such a way that it will drain, then pull open the valve.

When ready to leave park, close valve, Flush 5 to 10 gallons of water through your toilet, open the gate valve to allow complete drainage, re-close the valve and store the sewer hose.

Remember, this tank holds only the discharge from the toilet, not from sinks or shower. Therefore, water running out of the drain does not indicate a leaking septic tank valve but probably just that the sink or shower is draining.

If the toilet will no longer drain, this is an indication that the tank is full and will require emptying. . . watch this closely for when the tank is full the sewage cannot be emptied from the toilet bowl.

We recommend Airstream's specially designed sewer hose for use with this tank. Ask your dealer for details.